



Toyota Certified Gold

Vehicle Service Agreement



Backed by the
Strength and Stability of Toyota



Extended Protection Beyond Your Toyota Warranty

Bringing home a Toyota Certified Used Vehicle (TCUV) is a big investment and you want to make sure it's protected. A Toyota Certified Gold Vehicle Service Agreement (VSA) can help!

Our VSA is backed by Toyota and helps protect you from covered repair costs due to mechanical breakdown, beyond what's covered by your vehicle warranty. With service from Toyota-trained technicians and Toyota-approved parts, our VSA provides protection over time, so you can enjoy your vehicle for years to come.

or 100,000 miles
7
years

these benefits:

- \$50 DEDUCTIBLE
- 24/7 ROADSIDE ASSISTANCE
- SUBSTITUTE TRANSPORTATION
- TRAVEL PROTECTION
- TRANSFERABLE

+ Backed By Toyota

A Toyota Certified Gold VSA provides peace of mind for up to 7 years or 100,000 miles¹ with mechanical breakdown coverage, Roadside Assistance, substitute transportation and travel protection benefits. Plus, with the convenience of a \$50 deductible and plan transferability, we've got you covered.²

The fact is, the Toyota Certified VSA is the number one choice of Toyota Certified Used Vehicle owners!³



24/7 Roadside Assistance and Travel Protection

Your Trusted Roadside Companion

Drive confident with 24/7 Roadside Assistance. If the unexpected happens to occur, our VSA will help get you back up and running with:

- Towing to the nearest Toyota dealer
- Battery jump starts, flat tire and lockout assistance
- Delivery of up to 3 gallons of fuel
- Coverage anywhere in the U.S. and Canada

You'll be covered for the life of your Agreement so you can be on your way and leave the worrying to us.



Back in Business and Back On the Road

If you're unable to drive your Toyota due to the mechanical breakdown of a covered component, substitute transportation and travel protection benefits will provide reimbursements of up to:

- \$35 per day for car rentals or other substitute transportation⁴
- \$50 per day for lodging and meals if you're more than 150 miles from home⁴

You can rest assured you'll be back on the road in no time.

Thousands of Parts—One Plan

Extended protection for your vehicle—the Toyota Certified Gold VSA.

Provides protection for every covered component group,⁵ including all the parts listed below. Your vehicle's Powertrain Warranty covers only those parts listed in black.

ENGINE

All internally lubricated components and: Balance Shaft; Camshaft; Crankshaft; Crankshaft Pulley; Cylinder Heads; Engine Block; Engine Mounts; Engine Oil Reservoir; Engine Oil Reservoir Pump; Equipment Drive Shaft; Exhaust Manifolds; Flexplate; Flywheel; Idler Pulley; Intake Manifold; Oil Pan; Oil Pressure Switch; Oil Pump; Oil Sending Unit; Piston; Rotary Engine Components (including Apex Seal, Bearings, Eccentric Shaft, and Rotor); Seals and Gaskets; Supercharger; Supercharger Intercooler; Tensioners; Timing Belt; Timing Chain; Timing Cover; Timing Gears; Turbo Intercooler; Turbo Wastegate; Turbocharger; Valve Covers; Water Pump

MANUAL TRANSMISSION

Transfer Case Components (All internally lubricated components) and: Clutch Master Cylinder; Clutch Release Cylinder; Gears and Shafts; Hoses, Lines and Tubes; Seals and Gaskets; Shift Linkage and Cables; Transfer/Transmission Case; Transmission Mounts

AUTOMATIC TRANSMISSION

Transfer Case Components (All internally lubricated components) and: Hoses, Lines and Tubes; Seals and Gaskets; Shift Linkage and Cables; Solenoids; Torque Converter; Transfer/Transmission Case; Transmission Mounts; Vacuum Modulator

AXLE ASSEMBLY

(Front, Rear, Four-wheel and All-wheel Drive): All internally lubricated components and: 4x4 Actuators; Axles and Bearings; Center Support Bearing; Constant Velocity Joints and Boots; Drive Axle Housing; Drive Shaft; Hubs; Locking Hubs; Seals and Gaskets; Thrust Washers; Universal Joints; Viscous Coupling

SUSPENSION

(Front and Rear): Bushings/Bearings; Control Arm Shafts; Electronic Suspension Actuator/Motor and Compressor; Radius Arm; Spindle; Spindle Support; Steering Knuckle; Sway Bar Link; Upper and Lower Ball Joints; Upper and Lower Control Arms

STEERING


Gear Box internal components and: Bushings/Bearings; Center Link; Hoses; Lines and Tubes; Idler Arm; Pitman Arm; Power Steering Pump; Rack and Pinion; Seals and Gaskets; Steering Column; Steering Column Coupling; Steering Column Shaft; Steering Dampener; Steering Gear Box and Pump Housings; Tie Rod End

FUEL SYSTEM

Fuel Pump⁶; Air Flow Meter; Carburetor; Diesel Fuel Injection Pump; Electric Fuel Pump; Electronic Fuel Injection System; Fuel Injectors; Fuel Pressure Regulator; Fuel Sending Unit; Fuel Sensors; Fuel Tank; Throttle Body

COOLING SYSTEM

Cooling Fan Relay; Cooling Fan Sensor; Engine Cooling Fan Motor; Engine Fan; Engine Fan Clutch; Engine Fan Motor; Engine Fan Shroud; Fan Bracket Subassembly; Radiator; Seals and Gaskets; Thermostat



AIR CONDITIONING/HEATING

Air Conditioning Lines and Tubes; Air Conditioning Pressure Switches; Air Temperature Control Programmer; Blower Motor; Blower Motor Resistor; Compressor; Compressor Clutch Assembly; Compressor Pulley; Condenser; Condenser Fan and Motor; Evaporator; Evaporator Temperature Sensor; Expansion Valve; Heater Control Valve; Heater Core; Idler Pulley; Pressure Regulator Assembly; Receiver/Dryer; Schrader Valve; Seals and Gaskets

BRAKES

Anti-Lock Braking/Traction Control Actuator, Pump and Motor; Brake Booster; Brake Hoses, Lines and Tubes; Disc Brake Calipers; Load-Sensing Proportioning Valve; Master Cylinder; Parking Brake Cable; Proportioning Valve; Seals and Gaskets; Wheel Cylinders

HYBRID

Hybrid Vehicle Generator Assembly; Hybrid Vehicle Motor Assembly; Hybrid Vehicle Transaxle Assembly; Transmission Input Damper Assembly; Actuator Assembly Shift Control; Battery Computer Assembly; Battery Current Sensor; Circuit Breaker Sensor; Combination Meter Assembly; Combination Meter Computer; Engine Control Computer; Hybrid Vehicle Battery Blower Assembly; Hybrid Vehicle Battery Blower Motor Control; Hybrid Vehicle Battery Thermistor; Hybrid Vehicle Control Computer; Inverter Assembly with Converter; Main Switch Assembly; Power Source Control; Power Steering Electronic Control Unit (ECU) Assembly; Power Steering Gear Assembly; Shift Lever Position Sensor; Skid Control Computer Assembly; Steering Column Assembly; Transmission Control Module

ELECTRICAL

Alternator; Automatic-Off Headlamp Sensor Timer and Switches; Automatic Shoulder Belt Motor and Switches; Automatic Temperature Control Unit; Blower Motor; Blower Motor Resistor; Clutch Starter Interlock Switch; Convertible Top Motor; Cruise Control Actuator/Servo; Cruise Control Sensors and Switches; Cruise Control Vacuum Motor; Defogger Relay; Distributor; Engine Cooling Fan Motor; Headlamp Washer; Ignition Coil; Lamp Failure Indicator Sensor; Manually Operated Switches; Power Antenna Motor and Cable; Power Door Lock Actuator; Power Mirror Defogger; Power Mirror Motor; Power Seat Motors; Power Sliding Door Motor; Power Window Motor/Regulator; Retractable Headlamp Motor; Smart Entry and Start System Switch, Sensor and ECU; Starter Motor; Starter Solenoid; Stop Light Switch; Sunroof Motor; Windshield Washer Pump; Wiper Motor

COMPUTERS AND ELECTRONICS

Engine Control Computer;⁶ Anti-Lock Braking/Traction Control Computer and Sensors; Automatic Shoulder Belt Computer; Body Control Module; Cruise Control Computer; Electronic Ignition Unit; Electronically Controlled Transmission/Transfer Case Computer and Sensors; Electronically Modulated Suspension Computer; Knock Sensor; Power Mirror ECU; Power Seat Computer; Progressive Power Steering Computer; Sunroof Control Computer and Relay; Tilt/Telescoping Steering Computer; Trip Computer; Vehicle Security Computer and Sensor; Wiper Module

This protection is only available at the time you purchase your TCUV.

Ask for details today. To learn more, visit toyotafinancial.com/certifiedvsa or toyotacertified.com.

A Toyota Certified VSA offers:

- Extended protection for all covered vehicle component groups beyond your vehicle warranty
- 24/7 Roadside Assistance throughout the life of your Agreement
- Reimbursements for covered vehicle rentals, meals and lodging
- Access to a nationwide network of Toyota dealers throughout the U.S. and Canada
- Protection backed by the strength and stability of Toyota

To learn more about the wide range of programs offered by Toyota Financial Services and your participating Toyota dealer, visit us at toyotafinancial.com.



Start With Confidence.

The information in this brochure is provided as a sample of vehicle service agreement coverage. Coverage is subject to exclusions and limitations set forth in the vehicle service agreement. The actual coverage, exclusions and limitations of the agreements may vary both from state to state and according to the program features chosen. In certain states, Toyota Motor Services Company administers vehicle service agreements. Coverage is not available in all states.

¹ A Toyota Certified Gold VSA provides extended vehicle protection for up to 7 years from vehicle's date of first use as a new vehicle or 100,000 total vehicle miles, whichever comes first. See Agreement for complete terms, conditions and restrictions. Program is not available in all states.

² Deductible applies to each eligible repair visit; transferability is available for a nominal fee.

³ Based on CY10 sales data.

⁴ Car rental/substitute transportation reimbursements are provided for a maximum of 5 days per occurrence; lodging/meal reimbursements are provided for a maximum of 4 days over the life of the Agreement. Valid receipts are required for all reimbursements.

⁵ Covered components are subject to change. See your Agreement for complete details.

⁶ For hybrid vehicles, the Fuel Pump and Engine Control Computer are covered components under the Toyota Certified Used Vehicle Limited Powertrain Warranty.